

February 13, 2024



PRELIMINARY BUILD SPECIFICATION

Quote # QUO0000009378

Production # 21550

Document Rev. # 9

Status: Draft

Prepared For:

Chief Robert Chegan
NORTH ROYALTON/CITY OF
146 STATE ROAD
NORTH ROYALTON,
OH
44133
Phone: 4402374315

Presented By:

Debbie Ludewig
Horton Emergency Vehicles
3800 McDowell Road
Grove City, OH
43123
Phone: 800-282-5113

Option	QTY	Description
CHASSIS		
1000-0002	1	AMBULANCE SPECIFICATIONS
SR00263097	1	PREVIOUS VEHICLE REFERENCE 19232
SR00263049	1	CHASSIS, 2025 FREIGHTLINER M2, 174 The chassis required to complete the ambulance conversion shall be supplied by Horton.
1000-0093	1	CHASSIS ORDER SPECIAL COLOR. MED DUTY L4983EB PIERCE #106 ELITE BC DARK RED The chassis is to be ordered special color from chassis OEM.
SR00263073	1	CHASSIS - SPECIAL INSTRUCTIONS LIQUID SPRING BLACKOUT PACKAGE VERTICAL EXHAUST - MATCH HEIGHT FOR TRUCK 19232 CONDURA FABRIC CAB SEATS STEEL WHEELS PAINTED MICHELIN TIRES MUD AND SNOW TIRES REAR CHASSIS & FRAME PAINTED RED 40 GAL FUEL TANK BETWEEN THE REAR FRAME SCHRADER VALVE - LOCATE IN FORWARD UPPER SECTION OF THE DRIVER SIDE STEP COVER - JUST BELOW STEP

Spec Writer: **John Cox**

Spec Designer: **Joe Testa**

21550 NORTH ROYALTON FIRE DEPARTMENT

Option	QTY	Description
		NOTE- Once the 2024 chassis prices are released, we will update the chassis and chassis option pricing. VERIFY CHASSIS FRONT BUMPER HAS ACCOMMODATIONS FOR LICENSE PLATE PER DRAWING - DRILL AND TAP IF NOT PAINT THE UPPER AND LOWER EXHAUST PARTS WITH HIGH TEMP FLAT BLACK
1000-0086	1	CHASSIS ORDERED WITH STEEL WHEELS, MD The chassis will include steel OEM wheels.
1000-0065	1	WALK THROUGH FOR FREIGHTLINER Type 1 Freightliner chassis to be modified to provide walk through access to the patient area.
1000-0465	1	VALVE EXTENSIONS, STEEL WHEELS, FL Install stainless steel braided filler extensions on the rear tires. Fasten to the center wheel hub with stainless steel brackets.
1000-0073	1	TIRE SIZE, 19.5", MEDIUM DUTY: This chassis is specified to have 19.5" tires.
1000-0081	1	VERTICAL EXHAUST, FREIGHTLINER The chassis specified above is to include vertical exhaust.
1000-0083	1	STANDARD CAB HEIGHT The specified chassis will have the standard cab height.
1000-0259	1	MUD FLAPS FRONT, FREIGHTLINER Install mud flaps behind each front tire.
1000-0346	1	MUD FLAPS, REAR, LARGE W/LOGO Install individual rear mud flaps behind each set of rear wheels. Mud flaps to include Horton logo.
1000-0313	1	STEP/TANK TRIM SINGLE CAB FL, STD HEIGHT Install diamond plate step well covers on both the curb and street side cab step wells. The covers shall sized appropriately for a standard cab.
1000-0280	1	ENERGY ABSORBING FIXED STEP/EMBOSSED, FREIGHTLINER Install an energy absorbing rear step/bumper assembly with fixed center section. Material to be embossed diamondplate.
BODY		
SR00263048	1	FULL BLACKOUT PACKAGE TANK/STEP COVERS ALL COMPONENTS AROUND DEF FILL LICENSE PLATE BRACKET CORNER GUARDS THRESHOLDS SIREN SPEAKER HOUSINGS FUEL FILL HOUSING DOOR HANDLES

Spec Writer: **John Cox**Spec Designer: **Joe Testa****21550 NORTH ROYALTON FIRE DEPARTMENT**

Option	QTY	Description
		MOD WINDOW FRAMES TEMP SENSOR STONE GUARDS SILL PLATES GRILLE GUARD ENTIRE REAR BUMPER ASSEMBLY REAR RISER REAR ENTRY DOOR GRABBERS DRIP RAILS BLACK LIGHTING BEZELS
SR00263074	1	EXTERIOR SCREWS - COAT WITH ECK
SR00263095	1	FUEL FILL - STREETSIDE INSTALL A STREETSIDE FUEL FILL PER DRAWING. 40 GALLON FUEL FILL TANK LOCATED BETWEEN THE FRAME RAILS. APLY BLACK LINE-X TO HOUSING
2000-0173	1	AMBULANCE BODY Conversion model is to be a 623 using a Freightliner chassis. Body length is 173".
2000-0237	1	CRASH BARRIER SAFETY CONFIGURATION The side access door is to be relocated at the forward most area on the curbside of the body. The space between the door and the head of the bench is to be occupied by an inside/outside access compartment. Compartment to include standard LED strip lighting.
SR00263047	1	CRASH BARRIER - SPECIAL INSTRUCTIONS 1) COMPARTMENT SIZE 58.06"H x 36.37"W (ID) - WIDTH DIMENSION IS MINIMUM INSIDE COMPARTMENT WIDTH 2) INCLUDE SWEEP OUT FLOOR 3) INCLUDE 2 FLAT ALUMINUM ADJUSTABLE SHELVES CENTERED IN COMPARTMENT OPENING WITH NO LIPS 4) INCLUDE I/O ACCESS - CLEAR OPENING TO BE 25"H. 5) NOTE AISLE FACING DRAWER 6) STAINLESS STEEL SIL PLATE (LINE-X) 7) INSTALL RADIUS TRIM ONLY ON THE FORWARD EDGE OF THE CRASH BARRIER - 90 DEGREE TRIM ALL OTHER LOCATIONS
2000-0014	1	HEADROOM, 74" The headroom is to be 74".
2000-0625	1	ALUM. DIAMONDPLATE AT SIDE STEPWELL Fabricate the stepping surface inside the side access door using polished aluminum diamond treadplate.
2000-0245	1	DOUBLE STEP CURBSIDE ENTRY, 6" DROP SKIRT Fabricate curbside of body with 6" drop skirt. To include two step side entry.

Spec Writer: **John Cox**Spec Designer: **Joe Testa****21550 NORTH ROYALTON FIRE DEPARTMENT**

Option	QTY	Description
2000-0246	1	STREETSIDE 6" DROP SKIRT <p>Fabricate streetside of body with 6" drop skirt. </p>
2000-0250	1	SOUND PROOFING/ACOUSTIC ENHANCEMENT PACKAGE Install standard sound control package.
2000-1050	1	ROOF POCKET, AUXILIARY CONDENSER Install a roof pocket for a CoolTech I unit.
2000-0506	1	ELECTRONIC PRIVACY WINDOW For Rear Entry Doors Two (2) fixed electronic privacy windows shall be installed in the rear entry doors.
2000-0263	1	PRIVACY WINDOW, SLIDING FOR SIDE ENTRY DOOR Install a sliding tinted privacy window in the side access door.
2000-0265	2	EMERGENCY RELEASE, REAR DOORS Install standard emergency release knobs on top and bottom of the rear module entrance doors.
2000-0704	1	EMERGENCY RELEASE, SIDE ACCESS DOOR Install emergency release knobs on top and bottom of the side module entrance door.
2000-0010	1	DOOR HANDLES Install Tri-Mark free floating style door handles with pre-stretched stainless steel cables. Include three piece interior door panels on all access doors.
2000-0814	1	VI-TECH MOUNTING, FREIGHTLINER Install standard Vi-Tech body mounts.
2000-0269	1	STAINLESS STEEL SPLASH SHIELDS Install brushed stainless splash shields on the lower front face of the body just behind the cab access doors. These splash shields are to be the same height as the diamond plate front corner guards.
2000-0509	1	FENDERS, RUBBER Install rubber extruded fenders around the rear wheel well openings.
2000-0275	1	RUBBER RUB RAILS Rubber lower body rub rails are to be installed along the bottom of the body on each side fore and aft of the rear wheels.
2000-0652	1	STANDARD CORNER GUARDS Install standard height polished diamondplate corner guards.
2000-0281	1	REAR DOOR HOLD OPENS, GRABBER Install chrome Cast Products "Grabber" style rear door hold opens. (NOTE: HOLDOPENS MUST BE RELOCATED IF TELESCOPIC LIGHTS ARE ORDERED)
2000-0583	1	ENTRY DOOR THRESHOLDS, LINE-X Apply black Line-X to the side and rear entry door thresholds. Delete the standard anti-slip tape.
2000-0584	1	REAR RISER ADP The rear riser is to be fabricated out of polished aluminum diamondplate.
2000-0684	1	LICENSE PLATE BRACKET, CENTER OF RISER Install a recessed rear license plate bracket centered in the rear riser. Include an LED license plate light.
2000-0598	20	DOOR REFLECTORS

Spec Writer: **John Cox**
Spec Designer: **Joe Testa**

21550 NORTH ROYALTON FIRE DEPARTMENT

Option	QTY	Description
		All patient compartment entry doors to include standard red reflectors.
COMPARTMENTATION		
2900-1572	1	STREETSIDE FORWARD COMPARTMENTS The height of the streetside front compartment is to be the reduced. An electrical compartment is to be installed above the primary compartment. See drawings for compartment dimensions. Both compartments are to include standard LED strip lighting and single hinged doors. The upper compartment is to include a vent in the door. All electrical components usually installed in the intermediate compartment shall be relocated to this compartment.
SR00263070	1	STREETSIDE FORWARD - SPECIAL INSTRUCTIONS 1) INCLUDE SHORELINE ACCESS PANEL ON THE UPPER RIGHT WALL 2) INSTALL THE O2 BOTTLE BRACKET RAISED ABOVE THE FLOOR AS HIGH AS POSSIBLE AND STILL HAVE ACCESS TO THE REGULATOR - MATCH PREVIOUS 3) ADD STAIR CHAIR POCKET ON FORWARD DOOR 7"W x 40"H x 1.2"D
2000-0400	1	SS FORWARD COMPT. DIAMONDPLATE The streetside forward compartment is to be fabricated from diamondplate.
2000-0225	1	SWEEP OUT COMPARTMENT FLOOR, SS FRONT Streetside forward compartment floor is to be sweep-out style.
2900-0103	1	STAIR CHAIR POCKET, STREETSIDE FORWARD A stair chair pocket is to be recessed into the streetside forward compartment inner door panel. The pocket shall be installed as close to the bottom and hinged side of door as possible. See drawings for dimensions.
2900-0095	1	SILL PLATES, STREETSIDE FRONT Install a stainless sill plate on the streetside forward compartment.
2900-1574	1	STREETSIDE INTERMEDIATE COMPARTMENT The height of the streetside intermediate compartment is to be the full available height to the bottom of the interior countertop. See drawings for compartment dimensions. Compartment is to include standard LED strip lighting and double hinged doors.
2000-0402	1	SS INTRMDT COMPT. DIAMONDPLATE The streetside intermediate compartment is to be fabricated from diamondplate.
2900-4060	1	TOOL MOUNTING PLATE; STREETSIDE INT Install a .25" thick aluminum plate on the back wall of the streetside intermediate compartment. Plate is to have a D/A finish. Install (2) aluminum 'C' channels to the wall and secure the plate using the 'C' channels.
SR00263093	1	SS INTERMEDIATE - TOOL MOUNTING PLATES 1) BACK COMPARTMENT WALL - NOTCH TOOL BOARD FOR HOPS CLOSEOUT 2) BACK SIDE OF COMPARTMENT NOTCH FULL HEIGHT AND WIDTH

Spec Writer: **John Cox**Spec Designer: **Joe Testa****21550 NORTH ROYALTON FIRE DEPARTMENT**

Option	QTY	Description
2000-0624	1	SWEEP OUT COMPARTMENT FLOOR SS INTERMEDIATE COMPT Streetside intermediate compartment floor is to be sweep-out style.
2900-4005	1	SILL PLATES, STREETSIDE INTERMEDIATE Install a stainless sill plate on the streetside intermediate compartment.
8000-0145	1	SS WHEELWELL COMPARTMENT, DELETE Vehicle is not equipped with a streetside wheelwell compartment.
2900-1580	1	STREETSIDE REAR COMPARTMENT The height of the streetside rear compartment is to be half of the available height of the body. See drawings for compartment dimensions. Compartment is to include standard LED strip lighting and double hinged doors.
SR00263103	1	SS REAR - SPECIAL INSTRUCTIONS 1) INSTALL SINGLE COMPARTMENT DOOR ILOS 2) INSTALL 2 ANGLED ALUMINUM SCBA BRACKETS - ONE IN EACH REAR CORNER 3) REDUCE THE COMPARTMENT WIDTH 6" PER PREVIOUS.
2000-0404	1	SS REAR COMPT. DIAMONDPLATE The streetside rear compartment is to be fabricated from diamondplate.
2900-4007	1	SILL PLATES, STREETSIDE REAR Install a stainless sill plate on the streetside rear compartment.
2900-1583	1	CURBSIDE REAR COMPARTMENT The height of the curbside rear compartment is to be the full available height of the body. See drawings for compartment dimensions. Compartment is to include standard LED strip lighting and a single hinged door.
2000-0409	1	CS REAR COMPT. FLAT ALUMINUM The curbside rear compartment is to be fabricated from flat aluminum.
2900-4070	1	FIXED VERTICAL DIVIDER, CURBSIDE REAR ALIGNED AGAINST THE REAR SIDE OF CLOSE OUT Install a 16" deep fixed vertical divider in the curbside rear compartment. Locate as noted above.
2900-0266	1	ROK BACKBOARD STRAP CURBSIDE REAR LEFT SIDE OF DIVIDER - CENTER VERTICALLY Install a Rok buckle style backboard strap in the designated compartment.
2000-0611	1	SWEEP OUT COMPARTMENT FLOOR CS REAR COMPT Curbside rear compartment floor is to be sweep-out style.
2900-4001	1	STAIR CHAIR POCKET, CURBSIDE REAR A stair chair pocket is to be recessed into the curbside rear compartment inner door panel. The pocket shall be installed as close to the bottom and hinged side of door as possible. See drawings for dimensions.
2900-2956	1	STAIR CHAIR MODEL, STRYKER #6252 A Stryker #6252 stair chair will be stored as noted. This is for sizing/placement purposes only. Horton is not to supply this equipment.
2900-4008	1	SILL PLATES, CURBSIDE REAR

Spec Writer: **John Cox**Spec Designer: **Joe Testa****21550 NORTH ROYALTON FIRE DEPARTMENT**

Option	QTY	Description
		Install a stainless sill plate on the curbside rear compartment.
8000-0090	1	CS INTRMDT COMPT, DELETE Vehicle is not equipped with a curbside intermediate compartment.
8000-0143	1	CURBSIDE FRONT COMPT DOOR DELETE
3000-0126	1	PULL OUT TRAY FOR 3-BATTERY SYSTEM Install a custom battery tray for (3) batteries in the battery storage location.
2900-1141	1	MATEFLEX, TERRA COTTA Terra Cotta Mateflex is to be installed on the floor and shelving of all exterior compartments. To include tapered edge trim pieces where applicable.
SR00263057	1	MATEFLEX - INCLUDE SHELVES IN CRASH BARRIER
2900-0113	1	RUBBER WALLS IN BB COMPT, GRAY The interior of the backboard compartment is to be covered with gray rubber matting to protect equipment stored in this area.
2900-0114	1	GRIP LOCK, FACE OF EXTERIOR SHELVES AND DIVIDERS Install grip lock trim on the edges of the compartment shelves and any vertical dividers.
PAINT AND GRAPHICS		
5000-0189	1	MODULE PAINT FLNA 32207 RED TO MATCH CHASSIS The module body is to be painted a special paint color and paint code as noted above.
SR00263092	1	PAINT - VERTICAL EXHAUST SHEILD PAINT VERTICAL EXHAUST SHEILD FLNA 40019
5000-0014	1	PAINT PANEL: SAMPLE FLNA 32207 RED TO MATCH CHASSIS A painted test panel shall be prepared with the paint color and number noted above,
5000-0002	1	PAINT CHASSIS WHEELS FLAT BLACK The chassis outer wheels and spare, if provided, are to be painted.
SR00263059	1	PAINT 360 DEGREE CAMERA COVERS 360 CAMERA - PAINT BLACK
SR00263064	1	STRIPE - CUSTOM 1" BLACK SCOTCHLITE 1" GOLD SCOTCHLITE 6" BLACK SCOTCHLITE 1" GOLD SCOTCHLITE 1" BLACK SCOTCHLITE 1) STRIPE TO START ON FORWARD CHASSIS DOORS AND EXTEND STRAIGHT BACK ACROSS THE MODULE AND WRAP THE REAR CORNER POSTS AND STOP. 2) DO NOT EXTEND ACROSS REAR OF MODULE

Spec Writer: **John Cox**Spec Designer: **Joe Testa****21550 NORTH ROYALTON FIRE DEPARTMENT**

Option	QTY	Description
		3) LOCATE STRIPE SO THAT LOGO ON CAB DOOR IS CENTERED 4) INSTALL 2 CUSTOMER PROVIDED 18" NRRFD CRESTS ON CAB DOORS
SR00263094	1	REFLEXITE FRONT CHEVRON Install a Reflexite chevron on the front of the vehicle per drawings. Red #12 Lime #L2 FRONT CHEVRON - BUMPER
SR00263083	1	REFLEXITE CHEVRON, FULL REAR Install full rear body chevron pattern using Reflexite material. Install inboard or vertical corner posts and below upper drip rail. Red #12 Lime #L2 1) REAR CHEVRONS TO BE ONE PIECE 2) UPPER PART OF REAR DOORS DELETE CHEVRONS - PAINT RED FOR GRAPHICS
SR00263099	1	REFLEXITE CHEVRON, ACCESS DOOR PANELS Install a Reflexite chevron on the lower interior door panels on all body access doors. Red #12 Lime #L2
SR00263067	1	18" Non Shaded Scotchlite White Rooftop Helvetica Medium - M-2 (below cool tech) NRRFD (rear roof) copy previous
5100-0671	33	6" Shaded Scotchlite Gold Streetside of Body Helvetica Medium - NORTH ROYALTON FIRE DEPARTMENT MEDIC 1
5100-0969	33	6" Shaded Scotchlite Gold Curbside of Body Helvetica Medium - NORTH ROYALTON FIRE DEPARTMENT MEDIC 1
5100-1234	27	4" Shaded Scotchlite Gold Rear of Body Helvetica Medium - NORTH ROYALTON FIRE DEPARTMENT
SR00263063	1	LICENSE PLATES - FABRICATE/GRAPHICS

Spec Writer: **John Cox**Spec Designer: **Joe Testa****21550 NORTH ROYALTON FIRE DEPARTMENT**

Option	QTY	Description
		1) FABRICATE/INSTALL 2 LICENSE PLATES - ONE FOR FRONT AND FOR REAR 2) PAINT RED TO MATCH BODY COLOR 3) GRAPHICS - HELVETICA GOLD SCOTCHLITE WITH RELECTIVE BLACK OUTLINE AND DROP RIGHT SHADOW - "M-1" (USE TRANS. GOLD ON WHITE)
5000-0194	1	ACCESS DOORS DEMO STYLE R/W CHEVRON Install red/white printed Scotchlite demo style chevrons on the center inner door panels of all entry doors.
INTERIOR FEATURES		
SR00263046	1	GLOVE STORAGE - REAR ENTRY DOORS INSTALL 2 HORTON FABRICATED GLOVE BOXES PARTIALLY RECESSED INTO THE LOWER REAR ENTRY DOOR PANELS - ONE PER DOOR. INCLUDE HINGE UP ACRYLIC DOORS WITH OVAL ACCESS OPENINGS AND SOUTHCO SLAM LATCHES. PAD ALL EXPOSED EDGES. GLOVE BOX SIZE 10.5"W x 5.5"H x 5.0"D
SR00263075	1	GLOVE STORAGE - FRONT WALL INSTALL 2 GLOVE BOXES ON FRONT WALL PER DRAWING - INCLUDE HINGE UP ACRYLIC DOOR WITH OVAL ACCESS OPENINGS AND SOUTHCO LATCH. GLOVE BOX SIZE 10.5"W x 5.5"H x 5.0"D
2000-0288	1	ACRYLIC COLOR: LIGHT TINT All acrylic doors to be light tint.
2000-0825	2	COUNTERTOP, MERAPI INHALATION AREA & CRASH BARRIER Install solid surface countertop(s) in lieu of stainless steel. Material is to include radiused and tapered corners and is to have a polished finish. Color is to be Merapi. Locate as noted above.
2000-0592	1	PAINTED STANDARD INHALATION AREA WALLS The main wall action area walls are to be painted to match the remainder of the interior cabinets.
SR00263091	1	INHALATION PANEL, CARBON FIBER COVERED The inhalation panel is to be fabricated from composite material and covered with Black Carbon fiber. 1) COVER INHALATION PANEL WITH BLACK CARBON FIBER 2) INCLUDE 26" OF FREE SPACE REAR OF PANEL 3) REINFORCE REAR COUNTERTOP FOR FUTURE INSTALLATION OF MONITOR
SR00263107	1	GUNMETAL CG TECH INTERIOR COLOR The patient area walls, inner door panels (EXCLUDING the main cabinet wall and associated areas such as the action area, CPR seat and telemetry area when equipped) are to be finished with Gunmetal CG Tech material. Requires stainless risers and lower door panels.

Spec Writer: **John Cox**Spec Designer: **Joe Testa****21550 NORTH ROYALTON FIRE DEPARTMENT**

Option	QTY	Description
2000-0627	1	LONSEAL LONPLATE BLACK The patient area floor is to be covered in Lonplate Black.
SR00263090	1	MIRROR STAINLESS STEEL RISERS Install MIRROR stainless steel on the interior risers. If a cabinet riser accent stripe is ordered the stainless steel will stop at the bottom edge of the stripe. RISERS - MIRROR SS ILOS
SR00263102	1	MIRROR STAINLESS STEEL LOWER DOOR PANELS Finish lower section of inside patient compartment doors with MIRROR stainless steel. LOWER DOOR PANELS - MIRROR SS ILOS
2000-0678	1	GUNMETAL CABINET COLOR All interior cabinetry is to be painted Gunmetal.
2000-0709	1	CABINET PAINT TO BE SMOOTH The specified cabinet paint is to have a smooth finish.
2000-3007	1	BLACK VINYL COLOR All seat cushions and vinyl closeouts are to be covered in Black #8540 colored material.
2000-0326	1	STANDARD FIXED SEATBASE Install the standard aluminum fixed seat base for the attendant's seat specified.
2000-3127	1	USSC, BLACK 4-POINT, BLACK VINYL WITH CHILD SEAT Install a Black #8540 USSC high back bucket seat with built-in child safety seat and black 4pt seatbelt with safety vest. The seat to be adjustable front to rear and is to be mounted at the head of the cot.
2000-1754	1	OCCUPANT RESTRAINT. HEAD OF BENCH, BLACK Install an MBrace 4-pt seatbelt at the head position of the squad bench. Color is to be black.
2000-1758	1	OCCUPANT RESTRAINT. FOOT OF BENCH, BLACK Install an MBrace 4-pt seatbelt at the foot position of the squad bench. Color is to be black.
2000-0612	1	COMPOSITE INTERIOR CABINETS, GUNMETAL All applicable cabinetry to be fabricated from aluminum composite material. Color is Gunmetal Gray.
3000-1119	1	TUBULAR AIRBAG, ATTENDANT'S SEAT Install a tubular airbag at the attendant's seat. Unit uses an angled upper inhalation cabinet and includes a cabinet beneath the main countertop.
3000-1125	1	HEAD CURTAIN AIRBAG, ATTENDANT'S SEAT Install a head curtain air bag for the attendant's seat for use with a standard linen cabinet.
3000-1126	1	AIRBAG SENSOR

Spec Writer: **John Cox**Spec Designer: **Joe Testa****21550 NORTH ROYALTON FIRE DEPARTMENT**

Option	QTY	Description
		Install the standard airbag sensor in the standard location.
3000-1127	1	TUBULAR AIRBAG, CPR SEAT LOCATION. Install a tubular airbag forward of the CPR seat.
2000-0421	1	CABINET TRIM 90 DEGREE Install smooth 90 degree trim molding on all applicable interior cabinets.
SR00263056	1	RADIUS TRIM Include 1.5" radius trim on the forward portion of the crash barrier.
2000-0770	1	TECHNIMOUNT LIFEPAK 15 SHELF MOUNT Install a Technimount shelf mount for a Lifepak 15. This mount includes a base plate and is compliant wth Change Notice 10. Reinforce as needed.
SR00263051	1	LP15 NOTE Include a spacer same as counter top. Install mount 12" from rear of counter top.
2900-0079	1	IV HANGER, CP WITH RUBBER ARM COT HEAD Per Drawing Install a Cast Products recessed IV hanger with rubber arm over the cot head area.
2900-0212	1	IV HANGER, CP WITH RUBBER ARM COT FOOT PER DRAWING Install a Cast Products recessed IV hanger with rubber arm over the cot foot area.
2000-1313	1	GRAB RAIL: 8FT YELLOW ANTI SLIP, OVER COT Per Drawing Install 8 foot anti-slip main grab rail with yellow anti-microbial coating. Locate offset toward the main wall over the cot position in the patient area ceiling.
2000-1318	1	GRAB RAIL: 8FT YELLOW. ANTI SLIP, OVER BENCH PER DRAWING Install 8 foot anti-slip main grab rail with yellow anti-microbial coating. Locate offset toward the bench wall in the patient area ceiling.
2000-1301	1	VERTICAL RAIL, 2' YELLOW ANTI-SLIP, BOLSTER Install a 2 foot anti-slip grab rail with yellow anti-microbial coating. Locate on the bench bolster at the side access door angled upward toward the forward end.
2000-1309	1	VERT GRAB RAIL, 2' YELLOW ANTI-SLIP MAIN WALL Install a 2 foot anti-slip grab rail with yellow anti-microbial coating. Locate to the street side just inside the rear entry doors mounted vertically.
SR00263105	1	VERT GRAB RAIL, 4' YELLOW ANTI-SLIP REAR DOORS Install a 4 foot anti-slip grab rail with yellow anti-microbial coating. Locate to the curb side just inside the rear entry doors mounted vertically. GRAB HANDLE INSIDE REAR DOORS - CURBSIDE REAR - 4" ILOS
2000-1302	1	PATIENT DOOR GRAB RAILS: YELLOW/ANTI-SLIP Install standard 'V' shaped grab rails with yellow anti-microbial coating. Handles are to be anti-slip style. Locate on the interior door panels of all three patient entry doors.

Spec Writer: **John Cox**Spec Designer: **Joe Testa****21550 NORTH ROYALTON FIRE DEPARTMENT**

Option	QTY	Description
2000-0423	1	CEILING MATERIAL, PLATINUM WHITE COMPOSITE The standard module ceiling material shall be platinum white aluminum composite.
STREETSIDE CABINERY		
2000-0337	1	LINEN CABINET Install a standard storage cabinet behind the attendant seat.
SR00263054	1	LINEN CABINET - SPECIAL INSTRUCTIONS 1) ELECTRONICS CABINET TO BE 20.5"H 2) INSTALL A SIMPLEX LOCK ON THE LOWER LINEN CABINET DOOR
2900-1076	1	FIXED SHELF, UPPER LINEN CLOSET Fab and install a fixed aluminum shelf in the upper section of the linen cabinet. Shelf is to be painted to match the cabinet color.
2900-1079	1	ADJUSTABLE SHELF MIDDLE 1 LINEN CLOSET Fab and install an adjustable aluminum shelf in the middle section of the linen cabinet. Shelf is to be painted to match the cabinet color.
2900-1083	1	ADJUSTABLE SHELF LOWER LINEN CLOSET Fab and install an adjustable aluminum shelf in the lower section of the linen cabinet. Shelf is to be painted to match the cabinet color.
2900-2029	2	SOLID LAMINATE-COVERED LINEN CLOSET DOOR Install hinged solid doors on the linen cabinet. Cover in laminate to match the interior.
2900-1070	1	PIANO HINGE FOR LINEN CLOSET TOP DOOR The upper linen cabinet door(s) is/are to use piano style hinge.
2900-1074	1	PIANO HINGE FOR LINEN CLOSET LOWER DOOR The lower linen cabinet door(s) is/are to use piano style hinge.
2900-1056	1	SOUTHCO LOCKING LATCH, LINEN CABINET DOOR TOP, Install a stainless flush mount Southco locking pull latch on the upper linen cabinet door.
2900-1065	1	SOUTHCO LATCH FOR LINEN CABINET DOOR, LOWER Install a stainless flush mount Southco pull latch on the lower linen cabinet door.
2000-0343	1	STREETSIDE WALL WITH CPR SEAT Street side cabinet wall to include a CPR seat.
2000-1762	1	OCCUPANT RESTRAINT. CPR SEAT, BLACK Install an MBrace 4-pt seatbelt at the CPR seat position. Color is to be black.
2000-1799	1	CPR SEAT BACK CUSHION, BLACK The MBrace backrest cushions for the CPR seat are to be Black #8540 in color. Seat cushion and closeout colors are listed separately.
SR00263086	1	CPR SEAT, 42" WIDTH Streetside CPR seat width to be 42". 1) CPR SEAT TO BE 42"W WITH CENTERED SEAT BELT 2) CLOSE OFF FORWARD SECTION BELOW THE DRAWERS TO PREVENT ITEMS FROM SLIDING FORWARD UNDER DRAWER AREA

Spec Writer: **John Cox**Spec Designer: **Joe Testa****21550 NORTH ROYALTON FIRE DEPARTMENT**

Option	QTY	Description
2900-4087	1	ANGLED UPPER CABINET, FORWARD OF CPR SEAT The upper cabinet forward of the CPR seat is to be angled.
SR00263087	1	ANGLED CABINET NOTE Door to be vertically hinged on the left side, to open toward main wall.
2900-4094	1	STRAIGHT UPPER CABINET, AFT OF CPR SEAT 30.50"W x 38.75"H x 16"D The upper cabinet aft of the CPR seat is to be straight with no angle.
2900-1171	2	ADJUSTABLE SHELVING, REAR CPR CABINET Install painted adjustable shelving in upper cabinet aft of the CPR seat.
2900-1178	1	ACRYLIC SLIDING, REAR CPR CABINET Cabinet specified above is to have sliding acrylic doors.
2000-2058	1	UPPER INHALATION CABINET 52.75"W x 14.75"H x 16"D Upper inhalation cabinet dimensions are to be as noted above. Note that dimensions are I.D.
2900-1102	1	ACRYLIC SLIDING DOORS, UPPER INHALATION CAB. Cabinet specified above is to have sliding 3/8" acrylic doors.
2900-1094	1	INTERIOR SHELVING, UPPER INHALATION CABINET Install painted adjustable shelving in upper inhalation cabinet.
2000-0347	1	STORAGE BENEATH THE CPR SEAT Provide a hinged CPR seat cushion with storage located underneath.
2000-0349	1	GAS HOLD OPEN FOR LIFT UP CPR SEAT CUSHION Provide a gas holdopen on the flip-up CPR seat cushion to keep the cushion in the upright position when opened.
2000-0348	1	RECESSED PADDLE LATCH. CPR SEAT Provide a recessed paddle latch in the cabinet riser to secure access to the CPR seat storage area.
SR00263053	1	DRAWERS - INHALATION AREA 2 PAINTED DRAWERS UNDER REAR INHALATION AREA 33.25"W x 9"H x 12"D 30"W x 5.5"H x 10.25"D (ID) DRAWERS TO INCLUDE BOTTOM MOUNT SLIDES NOTE CPR SEAT STORAGE AND INTERMEDIATE COMPARTMENT NOTCHES
CURBSIDE CABINERY		
2000-0359	1	SQUAD BENCH WITH NO CUPS OR WELLS Provide storage under the squad bench lid/cushion(s). The area shall run where possible under the bench. The storage pan is to be fabricated from aluminum and painted to match the interior.

Spec Writer: **John Cox**Spec Designer: **Joe Testa****21550 NORTH ROYALTON FIRE DEPARTMENT**

Option	QTY	Description
2000-0743	1	SINGLE CUSHION SQUAD BENCH The squad bench cushion is to be one piece.
2000-0380	1	BENCH HOLD OPENS: GAS Install gas spring hold opens on squad bench lid.
2000-0585	1	BENCH HOLD-DOWN: PADDLE LATCHES (SINGLE) Install a recessed paddle latch into the squad bench riser to retain the squad bench lid in the closed position.
2000-0382	1	BENCH CUSHION EDGE TRIM: Trim bench cushion edge with protective aluminum trim, to protect horizontal edge of squad bench cushion from tears.
2000-1794	2	BENCH BACK CUSHION, BLACK The MBrace backrest cushions for the bench seating positions are to be Black #8540 in color. Seat cushion and closeout colors are listed separately.
SR00263068	1	BENCH SLIDING PAINTED DRAWER - LOCATED IN UPPER CRASH BARRIER 1) OPEN TOWARDS AISLE 2) INCLUDE GAS SHOCK TO HOLD IN THE OPEN AND CLOSED POSITION 3) SIZE 29"W x 16.25"D x 5"H (ID) 4) INSTALL WITH BOTTOM MOUNT SLIDES 5) INSTALL A SIMPLEX LOCK ON THE DRAWER PER DRAWING
SR00263066	1	CURBSIDE CABINETRY - 2 CUSTOM CABINETS 1) INSTALL A CABINET WITH ACRYLIC HINGE UP DOOR FORWARD OF THE BENCH OVERHEAD CABINETS SIZE 23"W x 11"H x 14"D 2) INSTALL AN ADDITIONAL CABINET FORWARD OF THE ABOVE CABINET WITH AN ACRYLIC HINGE UP DOOR SIZE 24"W x 18"H x 14"D - ADD ADJUSTABLE SHELF IN THIS CABINET
2900-0065	1	BENCH CABINET, HINGED DOORS Fabricate and install a bench ceiling cabinet above the squad bench with lift up 3/8" acrylic doors.
2900-1130	2	SOUTHCO LATCH OVERHEAD BENCH CABINET Install stainless flush mount Southco pull latches on the bench ceiling cabinet.
2900-1135	6	SELF CLOSING HINGE FOR OVERHEAD BENCH CABINET The bench ceiling cabinet door(s) is/are to use self-closing style hinges.
2900-0066	1	DIVIDER TRACK. CABINET OVER BENCH Install adjustable tracks inside of the cabinet referenced above. Tracks are to be routed acrylic material on the bottom and back wall of cabinet. The outer edge of the lower track is to be rounded to avoid any sharp edges. Dividers are selected separately.
2900-0069	15	CABINET DIVIDERS. CABINET OVER BENCH CABINET OVER BENCH Fabricate acrylic dividers to fit vertically into the specified track. The dividers shall be adjustable within the track.

Spec Writer: **John Cox**Spec Designer: **Joe Testa****21550 NORTH ROYALTON FIRE DEPARTMENT**

Option	QTY	Description
SR00263058	1	<p>BENCH WALL INSERT CABINET</p> <p>1) THIS WILL BE A CLOSED CABINET THAT OPENS OVER REAR BENCH 2) INSTALL CLOSEOUT IN CS REAR COMPARTMENT 3) ADD 2 EVENLY SPACED SHELVES 4) INSTALL EDGE PROTECTOR ON THE DOOR TO PREVENT IT FROM DAMAGING WALL WHEN OPENED 5) LEFT HINGED DOOR - ACRYLIC - SOUTHCO LATCH AT TOP OF DOOR - PIANO HINGE 6) INCLUDE A SIMPLEX MECHANICAL LOCK PER PREVIOUS.</p>
COT MOUNT		
SR00263069	1	<p>POWER LOAD, RAIL ONLY, CENTERED Cot Type: None</p> <p>Supply and install a floor plate assembly kit and wiring for a Stryker Power load system.</p> <p>Install an existing Power load system from old customer truck that will be dropped off at delivery. Locate in the center position.</p>
VISUAL WARNING		
3000-0043	1	<p>LIGHT BAR MOUNT: REAR FACE OF BODY</p> <p>Install the specified rear lightbar on the rear face of the body.</p>
3000-1236	1	<p>WHELEN TAL85, EIGHT LED TRAFFIC ADVISOR</p> <p>Install a Whelen TAL85, eight LED, 46.82" traffic advisor on the rear face of the ambulance body. Wire for operation through the Horton electrical system. Do not use a Whelen control head.</p>
SR00263080	1	<p>TRAFFIC ADVISOR NOTE</p> <p>Control head for the traffic advisor will be located on the console.</p>
3000-1808	1	<p>WIG WAG HEADLIGHTS, FREIGHTLINER</p> <p>Install wig wag headlight flasher. Provide a dedicated switch in the front control panel. Deactivate with high beams and in secondary mode.</p>
3000-5004	2	<p>M6 AMBER/CLEAR LENS ABOVE REAR ENTRY DOORS EITHER SIDE OF 360 CAMERA</p> <p>Install Whelen M6 series LED lights as noted. Lights to be amber with clear lenses. Lights to include chrome flanges and flash pattern programmability from the front control panel.</p>
SR00263079	1	<p>(4) M62VR LIGHTS</p> <p>1) INSTALL 2 M62VR COMBO LIGHTS ABOVE THE REAR ENTRY DOORS CENTERED BETWEEN THE RED AND AMBER M6 LIGHTS.</p> <p>2) INSTALL 2 M62VR COMBO LIGHTS ON THE LOWER SIDES OF THE MODULE BEHIND THE REAR WHEELS TO ACTIVATE AS WARNING AND ADDITIONAL BACK UP LIGHTING</p> <p>BLACK BEZELS</p>

Spec Writer: **John Cox**Spec Designer: **Joe Testa****21550 NORTH ROYALTON FIRE DEPARTMENT**

Option	QTY	Description
3200-5006	6	M6 RED/CLEAR LENS 2 ABOVE OUTBOARD EDGES OF REAR ENTRY DOORS, 2 REAR RISER BELOW TAIL LIGHT, 2 ABOVE MODULE WHEELS Install Whelen M6 series LED lights as noted. Lights to be red with clear lenses. Lights to include chrome flanges and flash pattern programmability from the front control panel.
3300-5009	2	M6 R/W SPLIT/CLEAR LENS EACH SIDE OF CAB HOOD - RED FORWARD Install Whelen M6 series LED lights as noted. Lights to be red/white split with clear lenses. Lights to include chrome flanges and flash pattern programmability from the front control panel.
3400-5018	4	M9 RED/CLEAR LENS 4 FRONT FACE (R) (R/W) (R) (PFP2) (R) (R/W) (R) Install Whelen M9 series LED lights as noted. Lights to be red with clear lenses. Lights to include chrome flanges and flash pattern programmability from the front control panel.
3500-5018	8	M9 RED/CLEAR LENS 2 STREETSIDE, 2 CURBSIDE, 2 REAR FACE UPPER CORNERS, 2 REAR FACE WINDOW LEVEL Install Whelen M9 series LED lights as noted. Lights to be red with clear lenses. Lights to include chrome flanges and flash pattern programmability from the front control panel.
3600-5021	2	M9 R/W SPLIT/CLEAR LENS 2 FRONT FACE (R) (R/W) (R) (PFP2) (R) (R/W) (R) Install Whelen M9 series LED lights as noted. Lights to be red/white split with clear lenses. Lights to include chrome flanges and flash pattern programmability from the front control panel.
3000-0141	1	FLASH PATTERN, DOUBLE A, B, C, D Program the emergency lighting flash pattern to Double A/B/C/D.
SR00263100	1	EMERGENCY LIGHTS - PROGRAMMING 1) PROGRAM ALL WARNING LIGHTS FOR RAPID DOUBLE FLASH PATTERN 2) ALL WARNING LIGHTS TO REMAIN ACTIVE IN SECONDARY EXCEPT FOR WHITE LIGHTS 3) PROGRAM WHITE LIGHTS TO SHUT OFF WITH CHASSIS PARK BRAKE SET
3000-0994	1	RED/CLEAR LENS M6 LED GRILLE, TOP Install (2) Whelen M6 Series red LEDs with clear lenses in the upper chassis grille. To include bezels where applicable and flash pattern programmability from the front control panel.
3000-1001	1	RED/CLEAR LENS M6 LED GRILLE, BOTTOM Install (2) Whelen M6 Series red LEDs with clear lenses in the lower chassis grille. To include bezels where applicable and flash pattern programmability from the front control panel.
3000-3495	1	WHITE/CLEAR LENS M4 LED INT. LIGHTS Install Whelen M4 series LED lights as intersection lights on each side of the chassis. Lights to be white with clear lenses. Lights to include chrome flanges and flash pattern programmability from the front control panel.
SR00263071	1	FOG LIGHTS - PIAA INSTALL 2 PIAA RF6 #07206 LED FOG LIGHTS BELOW THE FRONT BUMPER

Spec Writer: **John Cox**Spec Designer: **Joe Testa****21550 NORTH ROYALTON FIRE DEPARTMENT**

Option	QTY	Description
AUDIBLE WARNING		
2000-0434	1	AIR HORNS: OEM ON HOOD, WITH CHASSIS The chassis is to include OEM airhorns.
SR00263096	1	AIR HORN - ACTIVATION CHASSIS INCLUDES DUAL LAYNARD FROM OEM ADD 2 CHROME PUSH BUTTONS ONE ON EACH SIDE OF THE CONSOLE.
3000-0174	1	SIREN: WHELEN HFS295C9 Speaker 1- Wail, Yelp, Pierce. Speaker 2- Wail, Yelp, Pierce Install a Whelen HFS295C9 siren in the front console.
3000-1544	1	SPEAKERS, CAST PRODUCTS, FREIGHTLINER Install Cast Products siren speakers, applicable to Freightliner chassis, in the front bumper.
NON-EMERGENCY LIGHTING		
3000-0208	1	KKK SIDE BODY MARKER LIGHTS, M6 SERIES LED (PAIR) Install red Whelen M6 series LED turn/marker lights on each rear side of the module body. Lights provide module body night time side lighting visibility and turning signal indication. Lights do not flash with warning lights unless otherwise specified. Includes chrome flanges.
SR00263055	1	SIDE BODY MARKER LIGHTS - PROGRAMMING IATS PROGRAM TO FLASH WITH THE WARNING FLASHERS - TURN SIGNAL TO OVERRIDE WARNING FLASHERS
3000-1869	1	FOG LIGHTS, HELLA CLEAR, FREIGHTLINER Install clear #550 Hella fog lights on front bumper. Wire to a switch in the front console.
3000-0217	1	LED EXTERIOR COMPARTMENT LIGHTING Install full height LED strip lighting in all exterior compartments with the exception of any wheelwell compartments. Install vertical strips inside both sides of each compartment. The lights are to be directed toward the back of each compartment.
3000-0711	1	WELDON LED MARKER LIGHTS Weldon LED ICC marker lights are to be installed. Do not install in cases where a selected lightbar already includes ICC marker lights.
SR00263078	1	WHELEN PFH2 DUAL PANEL PIONEER FLOODLIGHT - FRONT MODULE INSTALL FRONT CENTER OF MODULE IN LINE WITH OTHER WARNING LIGHTS
3000-1625	1	WHELEN PFP2 DUAL PANEL STREETSIDE CENTER Install a Whelen PFP2 dual panel super LED floodlight on the streetside of the body in the center position. Install using a PBA203 semi-recess housing.
3000-1624	1	WHELEN PFP2 DUAL PANEL CURBSIDE CENTER Install a Whelen PFP2 dual panel super LED floodlight on the curbside of the body in the center position. Install using a PBA203 semi-recess housing.
3000-1438	1	TAIL LIGHTS, M6 SERIES, HORIZONTAL MOUNTED

Spec Writer: **John Cox**Spec Designer: **Joe Testa****21550 NORTH ROYALTON FIRE DEPARTMENT**

Option	QTY	Description
		Install Whelen M6 series LED stop/tail, turn, and reverse lights. Install the stop/tail and reverse lights in the rear riser/kick plate with brake/tail outboard. Install the turn signals above in the rear body panels. Lights to include chrome flanges.
3000-0267	1	ARROW LIGHTS M6 SERIES LED, FRONT Install (2) Whelen M6 series LED turn signals on the front face of the body below the outboard flashers and wire into the turn signal circuit. Lights to include chrome flanges.
ELECTRICAL		
SR00263050	1	ELECTRONIC PRIVACY WINDOWS - SWITCH LOCATIONS 1) SIDE ENTRY DOOR 3 SWITCH CONTROLPANEL 2) REAR ENTRY DOOR 3 SWITCH CONTROL PANEL 3) REAR CONTROL PANEL
3000-0018	1	ELECTRIC DOOR LOCKS COMPARTMENT EXTERIOR Install power activated door locks on all exterior compartment doors. Locks to be activated by a switch at each patient area access door. Locks may be overridden by a door key.
3000-0019	1	ELECTRIC DOOR LOCKS ACCESS DOORS INTERIOR Install power activated door locks on all patient area access doors. Locks to be activated by a switch at each patient area door. Locks may be overridden by a manual slide lever or by the door key.
3000-0022	1	ELECTRIC DOOR LOCKS WIRED TO OEM SWITCHES The specified power door locks are to be wired to the chassis OEM door lock switches.
3000-0020	1	ELECTRIC DOOR LOCKS CONCEALED IN GRILLE Install a concealed switch in the chassis grille to operate the power door lock circuit. Doors shall be wired to unlock only on this circuit.
3000-0456	1	REAR RADIO SPEAKERS OVER REAR PATIENT Install two (2) rear AM/FM radio speakers in the patient compartment ceiling over the foot of the cot. Provide volume control in the rear switch panel.
3000-0401	1	I4G+ ELECTRICAL SYSTEM. Install the Intelliplex i4G+ electrical system. System is to include a USB port installed under the dash for ease of programming.
3000-0305	1	INPOWER BATTERY SWITCH, WITH WAKE BUTTON 5 min. Install an Inpower electronic battery switch. Switch is to activate battery power through the vehicle ignition and is to include an automatic shutdown timer to deactivate battery power after the ignition is turned off. To include a wake button installed on the front console to activate the electrical system without using the key.
3000-1513	1	LIFESINE INVERTER/CHARGER, ON DEMAND Install a Vanner #LSC12-1100 LifeSine Inverter/charger in the dedicated electrical compartment as noted. Unit is to function 'on demand'. Status panels are selected separately.
3000-0310	3	110V INTERIOR OUTLET 1 FWD INHALATION WALL, 1 ABOVE CRASH BARRIER, 1 BOTTOM OF LINEN CABINET Install a 110V outlet(s) as noted.
3000-0549	3	INTERIOR 12VDC OUTLETS: CL TYPE/USB 1 FWD INHALATION WALL, 1 ABOVE CRASH

Spec Writer: **John Cox**Spec Designer: **Joe Testa****21550 NORTH ROYALTON FIRE DEPARTMENT**

Option	QTY	Description
		BARRIER, 1 BOTTOM OF LINEN CABINET Install a 12VDC cigarette style/USB outlet(s) as noted. Wire battery hot.
3000-1457	1	SHORELINE 1, 20A AUTO EJECT, RED Mount a Kussmaul Auto Eject 20 amp shoreline inlet in the standard location. Unit is to include a dynamic disconnect. Cover is to be red.
SR00263081	1	SHORELINE - ACCESS PANEL INSTALL AN ACCESS PANEL ON THE UPPER RIGHT WALL OF THE STREETSIDE FORWARD COMPARTMENT FOR SHORELINE WIRING MAINTENANCE
3000-1500	1	PD BOX LOCATION, LEFT HAND SIDE, SS INT. COMPARTMENT Install the power distribution panel on the left hand side of the streetside intermediate compartment. Close off this area from the remainder of the compartment.
3000-0324	1	SHORELINE INDICATOR 1: Install an indicator pilot light to show power to A.C. circuits and presence of activated primary shoreline.
3000-0327	1	EXTRA 12VDC CIRCUIT BREAKER: INTERMEDIATE COMPT An extra circuit breaker shall be installed in the streetside intermediate compartment.
3000-0332	1	REPORT LIGHT, LED Install a 12" LED report light on the action wall to light the counter area.
3000-0340	1	CLOCK, DIGITAL W/SECONDS: OVER REAR DOORS Install a Horton large face digital 12/24 hour clock with seconds display over the rear doors.
3000-0344	1	STEP WELL LIGHT VISTA LED Install a 10.5" LED Vista light strip in the standard location on the bench side of the step well. Light to activate with door open.
3000-0346	1	2.5" CAB CEILING LIGHTS, WHITE/RED LED Install (2) combination white/red LED dome lights in the cab headliner. Locate one light over the driver and one light over the passenger. Wire to a switch in the front control panel and provide 'OFF'. 'CLEAR' and 'RED' selections.
SR00263077	1	CAB CEILING LIGHTS - ACTIVATION ILOS INCLUDE 2 SEPARATE ROCKER SWITCHES TO CONTROL THE DOME LIGHTS THROUGH THE i4G SYSTEM. LOCATE ON CONSOLE TOP PLATE PER DRAWINGS
3000-0350	1	ROM DUROLUMEN LED ABOVE HEAD IN CEILING A ROM Durolumen light fixture shall be provided and installed as noted above. Fixture is to be operable from the rear switch panel as well as through other means as noted within this document.
SR00263060	1	ROM DUROLUMEN LED ABOVE ATTENDANT SEAT IN CEILING A ROM Durolumen light fixture shall be provided and installed as noted above. Fixture is to be operable from the rear switch panel as well as through other means as noted within this document.

Spec Writer: **John Cox**Spec Designer: **Joe Testa****21550 NORTH ROYALTON FIRE DEPARTMENT**

Option	QTY	Description
3000-0584	1	ROM DUROLUMEN LED ABOVE FOOT IN CEILING A ROM Durolumen light fixture shall be provided and installed as noted above. Fixture is to be operable from the rear switch panel as well as through other means as noted within this document.
3000-0359	8	PATIENT CEILING DOME LIGHTS WHELEN LED Install Whelen 80COEHCR LED dome lights in the patient area ceiling. The lights will have a high/low feature with the switch in the rear control panel.
3000-0361	1	LUMALIER #ADU-136 UV DISINFECTANT SYSTEM Install a Lumalier #ADU-136 UV disinfectant light in the patient area ceiling. Wire to operate on a timer with the door closed via a switch on the vehicle exterior. The system is to deactivate if a door is opened.
3000-0524	1	3 SWITCH PANEL OVERHEAD OF BENCH Install an i4G 3-switch control panel on the bench curbside wall over the head of the bench.
3000-2112	1	TIMER, FLUOR/LED, OVERHEAD BENCH Install an electronic momentary touch timer switch in the specified I4g switch panel on the wall over the head of the squad bench. The switch will enable time limited operation of the specified fluorescent/LED check-out lights with the battery switch in the 'off' position. Set timer to 15 minutes.
SR00263082	1	DUROLUMEN TIMER = 15 MIN
3000-0525	1	3 SWITCH PANEL REAR DOOR PANEL Install an i4G 3-switch control panel on the right rear entry door panel.
3000-2113	1	TIMER, FLUOR/LED, REAR DOOR PANEL Install an electronic momentary touch timer switch in the specified I4g switch panel on the right rear entry door panel. The switch will enable time limited operation of the specified fluorescent/LED check-out lights with the battery switch in the 'off' position. Set timer to 15 minutes.
3000-5042	1	DUMP OVERRIDE, i4G, REAR DOOR PANEL Install the dump override switch in the panel selected for the right rear entry door inner panel.
SR00263085	1	DUROLUMEN TIMER = 15 MIN
SR00263052	1	GO LIGHT - COLOR BLACK
3000-0007	1	BACKUP ALARM RESET, MOMENTARY Install a back-up alarm and provide a momentary backup alarm reset button on the front console.
3000-1905	1	360 CAMERA SYSTEM, WHITE Install a Horton 360 Degree camera system with white covers and integral lighting. The lighting is to have the ability to function in emergency response mode. The display will function in conjunction with the turn signals and when the vehicle is in reverse gear. Install rear housing if space is available. If space is unavailable then install camera only.
PROGRAMMING		

Spec Writer: **John Cox**Spec Designer: **Joe Testa****21550 NORTH ROYALTON FIRE DEPARTMENT**

Option	QTY	Description
SR00263106	1	PROGRAM, WARNING LIGHTS - DIMMING 1) Program lights to go into secondary automatically when truck is in park. 2) WARNING LIGHTS TO DIM TO 60% WHEN HEADLIGHTS ARE TURNED ON.
6000-0001	1	LIGHT PROGRAMMING: SIDE REAR SCENE The side rear scene lights shall be wired to transmission reverse, plus standard mode of operation.
6000-0002	1	LIGHT PROGRAMMING: RIGHT SIDE SCENE The right side scene lights shall come "on" when the side patient door is opened.
6000-0003	1	LIGHT PROGRAMMING: LOAD LIGHT Program the rear load lights to activate with transmission reverse plus the standard mode of operation.
6000-0018	1	WHITE LIGHT CUTOFF SWITCH Provide a switch in the front control panel to deactivate all forward facing white lights. This includes wig wag flashers if ordered.
6000-0006	1	PROGRAMMING: AUDIBLE LOW VOLTAGE ALARM Program an audible alarm to activate if the voltage drops below 11.8 volts for 120 seconds.
6000-0007	1	LIGHT PROGRAMMING: PARK BRAKE Program a warning to display on the front console readout advising to set the Parking Brake when the module disconnect switch is "ON" and the transmission is placed in "PARK" or "NEUTRAL". It will also advise to Disengage the Parking Brake should the vehicle be placed into gear.
6000-0010	1	LIGHT PROG: BRAKE LIGHT, BRAKE OVERRIDE Program the lower red flashing warning lights to operate as supplemental brake lights. The brake light feature is to override the warning mode. Once the brake is released then the lights should return to flashing.
SR00263061	1	BRAKE OVERRIDE PROGRAM WINDOW LEVEL M9 LIGHTS AS BRAKE LIGHTS ACTIVATE REGARDLESS OF MODULE DISCONNECT STATUS PROGRAM FOR SIGNAL ALERT FLASH.
3000-1269	1	MODULE DISCONNECT, DEFAULT TO "ON" Program the Module Disconnect to 'On' with battery activation.
HVAC		
3000-4027	1	12V HVAC, ATTENDANT'S SEAT Install a Pre-charged 12V heat/AC system with brushless motor below the attendant seat.
3000-3012	1	COOLTECH I, FL. Install a Cool-Tech I 4-fan 100,000 BTU condenser in the recessed pocket in the roof of the body.
SR00263101	1	VENT CAST PAINTED NFPA STYLE, NEGATIVE PRESSURE Install an NFPA style venting system to include (2) 400cfm exhaust fans. Install 9.5" square cast covers on both vents per drawings. Covers to be painted body color. Provide

Spec Writer: **John Cox**Spec Designer: **Joe Testa****21550 NORTH ROYALTON FIRE DEPARTMENT**

Option	QTY	Description
		"VENTILATION" and "NEGATIVE PRESSURE" functions. INSTALL 2 POWER VENTS TO CREATE NEGATIVE PRESSURE OPTION IN MODULE
3000-0431	1	CO DETECTOR: Install a 12V carbon monoxide detector in the patient area per drawings.
RADIO		
SR00263104	1	CUSTOMER SUPPLIED ANTENNA COAX 1 Start: Cab Console, End: Front Center of Mod Roof
SR00263076	1	CUSTOMER SUPPLIED ANTENNA COAX 2 INSTALL CUSTOMER PROVIDED ROUTER ANTENNA ABOVE COMPARTMENT 1 - SEE PROVIDED PHOTO FOR LOCATION - TERMINATE THE COAX IN THE ELECTRICAL COMPARTMENT
SR00263062	1	CUSTOMER SUPPLIED ANTENNA COAX 3 Start: Inhalation Wall, End: Rear Center of Mod Roof
3000-0434	1	3/8" NMO MOUNT COAX 1 Supply and install a 3/8" NMO mount in conjunction with specified coax #1.
3000-0618	1	3/8" NMO MOUNT COAX 2 Supply and install a 3/8" NMO mount in conjunction with specified coax #2.
3000-0619	1	3/8" NMO MOUNT COAX 3 Supply and install a 3/8" NMO mount in conjunction with specified coax #3.
3000-0438	1	RADIO HEAD PRE-CUT: FRONT Motorola O5 Provide a radio head pre-cut in the front console faceplate. Radio head model is noted.
3000-0627	1	RADIO HEAD PRE-CUT: REAR Motorola O5 Provide a radio head pre-cut in the rear inhalation panel. Radio head model is noted.
1000-0414	1	CONSOLE, LINE-X, W/MAP STORAGE, FREIGHTLINER Fabricate and install an aluminum cab console and spray with black Line-X material. Console is to include three (3) map/book slots at the rear of the console.
SR00263072	1	CONSOLE - SPECIAL INSTRUCTIONS 1) INSTALL A CUSTOMER PROVIDED I-PAD MOUNT ON THE FRONT OF THE CONSOLE 2) ROCKER SWITCHES FOR CAB LIGHTS ARE TO BE MOUNTED ON THE OUTBOARD EDGE OF THE FACEPLATE - ONE PER SIDE 3) TRAFFIC ADVISOR CONTROL HEAD TO BE LOCATED AT THE BOTTOM OF THE FACEPLATE CENTER 4) INCREASE THE AMOUNT OF ANGLE ON THE FRONT CONSOLE BY 10 DEGREES WHERE i4G IS LOCATED TO REDUCE GLARE 5) REAR EXTENSION AREA TO BE 9.5"L WITH 1 ADJUSTABLE DIVIDER
1000-0177	1	CUP HOLDERS, JUMBO 4"

Spec Writer: **John Cox**Spec Designer: **Joe Testa****21550 NORTH ROYALTON FIRE DEPARTMENT**

Option	QTY	Description
		Install two (2) jumbo 4" cup holders recessed into the console.
SR00263089	1	RADIO CABLES - CUSTOMER SUPPLIED INSTALL 2 RADIO CUSTOMER SUPPLIED RADIO CABLES 1) INHALATION PANEL - BEHIND DRIVER SEAT 2) FRONT CONSOLE - BEHIND DRIVER SEAT
3000-5156	1	POWER TERMINAL, DUAL, BEHIND DRIVER Install three (3) 10 gauge 30 amp cables to positive and ground studs behind the driver's seat for radio power. Wire one constant hot, one ignition hot and a ground.
3000-5157	1	POWER TERMINAL, DUAL, INSIDE CONSOLE Install three (3) 10 gauge 30 amp cables to positive and ground studs for radio power. Wire one constant hot, one battery switched, and the third as a ground.
3000-5160	1	POWER TERMINAL, DUAL, INHALATION PANEL Install three (3) 10 gauge 30 amp cables to positive and ground studs for radio power. Wire one constant hot, one battery switched, and the third as a ground.
OXYGEN		
4000-0001	1	O2 MOUNT, VERT TRACK FOR QRM-V Vertical track for mounting of a QRM-V O2 bottle mount shall be welded on the back wall of the streetside forward compartment in the right hand corner. Bracket will be set up for an 'M' sized bottle.
4000-0018	1	O2 BOTTLE, BRACKET QRM-V Install a Zico QRM-V oxygen bracket for 'M' bottle. Locate in the streetside forward compartment.
SR00263088	1	O2 BOTTLE - LOCATION INSTALL THE O2 BOTTLE MOUNT ABOVE THE COMPARTMENT FLOOR AS HIGH AS POSSIBLE PER DRAWING FOR "M" OR "H" TANK - DUPLICATE PREVIOUS
4000-0011	1	O2 TRANSFILL SYSTEM W/10' STAINLESS HOSE Plumbing shall be provided inside the O2 compartment for remote filling of the O2 bottle. Feature is to include a 10' stainless steel hose.
SR00263084	1	O2 TRANSFILL SYSTEM REMOTE MOUNT THE TRANSFILL SYSTEM ON THE RIGHT WALL OF THE #1 COMPARTMENT AND COVER WITH A PROTECTIVE SHIELD
4000-0019	1	OXYGEN ACCESS Provide access to the oxygen cylinder valve through the wall as depicted on the drawings. The door shall be hinged so that it swings into the oxygen cylinder storage compartment. Door material is to match other selected cabinet doors. The opening shall be 7" wide x 11" high and trimmed with anodized aluminum.

Spec Writer: **John Cox**Spec Designer: **Joe Testa****21550 NORTH ROYALTON FIRE DEPARTMENT**

Option	QTY	Description
4000-0021	4	O2 OUTLET, NCG STYLE 2 INHALATION PANEL, 1 BENCH WALL ABOVE CRASH BARRIER, 1 CEILING WAIST OF COT Install O2 outlets per instructions above. Outlets to be NCG style.
4000-0024	2	FLOWMETER: DIAL TYPE Supply dial type flowmeter.
4000-0025	1	OXYGEN WRENCH Install oxygen wrench in oxygen compartment. Mount securely to wall. Mount with length of chain or cable to allow for use without being removed from the compartment.
CERTIFICATIONS		
7000-0001	1	KKK-A-1822F CERTIFICATION LABEL The vehicle shall have weight/payload, electrical load and KKK-A-1822F certification stickers installed in the O2 compartment.